



V34 Software User Guide

1VV0301590 Rev. 0 – 2019-03-19

TELIT
TECHNICAL
DOCUMENTATION

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

NOTICES LIST

While reasonable efforts have been made to assure the accuracy of this document, Telit assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. The information in this document has been carefully checked and is believed to be reliable. However, no responsibility is assumed for inaccuracies or omissions. Telit reserves the right to make changes to any products described herein and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Telit does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others.

It is possible that this publication may contain references to, or information about Telit products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Telit intends to announce such Telit products, programming, or services in your country.

COPYRIGHTS

This instruction manual and the Telit products described in this instruction manual may be, include or describe copyrighted Telit material, such as computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Telit and its licensors contained herein or in the Telit products described in this instruction manual may not be copied, reproduced, distributed, merged or modified in any manner without the express written permission of Telit. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit, as arises by operation of law in the sale of a product.

COMPUTER SOFTWARE COPYRIGHTS

The Telit and 3rd Party supplied Software (SW) products described in this instruction manual may include copyrighted Telit and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and other 3rd Party supplied SW certain exclusive rights for copyrighted computer programs, including the exclusive right to copy or reproduce in any form the copyrighted computer program. Accordingly, any copyrighted Telit or other 3rd Party supplied SW computer programs contained in the Telit products described in this instruction manual may not be copied (reverse engineered) or reproduced in any manner without the express written permission of Telit or the 3rd Party SW supplier. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit or other 3rd Party supplied SW, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

USAGE AND DISCLOSURE RESTRICTIONS

I. License Agreements

The software described in this document is the property of Telit and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

II. Copyrighted Materials

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Telit

III. High Risk Materials

Components, units, or third-party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities"). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

IV. Trademarks

TELIT and the Stylized T Logo are registered in Trademark Office. All other product or service names are the property of their respective owners.

V. Third Party Rights

The software may include Third Party Right software. In this case you agree to comply with all terms and conditions imposed on you in respect of such separate software. In addition to Third Party Terms, the disclaimer of warranty and limitation of liability provisions in this License shall apply to the Third Party Right software.

TELIT HEREBY DISCLAIMS ANY AND ALL WARRANTIES EXPRESS OR IMPLIED FROM ANY THIRD PARTIES REGARDING ANY SEPARATE FILES, ANY THIRD PARTY MATERIALS INCLUDED IN THE SOFTWARE, ANY THIRD PARTY MATERIALS FROM WHICH THE SOFTWARE IS DERIVED (COLLECTIVELY "OTHER CODE"), AND THE USE OF ANY OR ALL THE OTHER CODE IN CONNECTION WITH THE SOFTWARE, INCLUDING (WITHOUT LIMITATION) ANY WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE.

NO THIRD PARTY LICENSORS OF OTHER CODE SHALL HAVE ANY LIABILITY FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST PROFITS), HOWEVER CAUSED AND WHETHER MADE UNDER CONTRACT, TORT OR OTHER LEGAL THEORY, ARISING IN ANY WAY OUT OF THE USE OR DISTRIBUTION OF THE OTHER CODE OR THE EXERCISE OF ANY RIGHTS GRANTED UNDER EITHER OR BOTH THIS LICENSE AND THE LEGAL TERMS APPLICABLE TO ANY SEPARATE FILES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

APPLICABILITY TABLE

PRODUCTS

■ ■ SL869T3-I

SOFTWARE

■ ■ V34-0.0.1-NVC-4.X.11A5-A01

■ ■ V34-0.0.1-NVC-4.5.11.10EB-B04

DRAFT

CONTENTS

NOTICES LIST	2
COPYRIGHTS	2
COMPUTER SOFTWARE COPYRIGHTS	2
USAGE AND DISCLOSURE RESTRICTIONS	3
APPLICABILITY TABLE	4
CONTENTS	5
TABLES 7	
1. INTRODUCTION	8
2. COMMUNICATION INTERFACE	11
2.1. Serial Communication	11
2.2. Talker ID	11
2.3. Proprietary NMEA Message Format	11
3. NMEA OUTPUT MESSAGES	13
3.1. Standard NMEA Output Messages	13
3.1.1. GGA – Global Positioning System Fix Data	13
3.1.2. GSA – GNSS DOP and Active Satellites	14
3.1.3. GSV – GNSS Satellites in View	15
3.1.4. RMC – Recommended Minimum Specific GNSS Data	17
4. PROPRIETARY NMEA MESSAGES	19
4.1. PSTMGETSWVER – Poll SW Version	19
4.1.1. Input Message	19
4.1.2. Output Message	19
4.2. PSTMINITGPS – GPS Initialize	19
4.2.1. Input Message	19
4.2.2. Output Message	20
4.3. PSTMINITTIME – Time Initialize	21
4.3.1. Input Message	21
4.3.2. Output Message	21
4.4. PSTMCLREPHS – Clear Ephemeris	22
4.4.1. Input Message	22
4.5. PSTMDUMPEPHEMS – Dump Ephemeris	22

4.5.1.	Input Message	22
4.6.	PSTMEPHEM – Load Ephemeris	23
4.6.1.	Input Message	23
4.6.2.	Output Message	23
4.7.	PSTMNMEAONOFF – Enable/Disable NMEA	24
4.7.1.	Input Message	24
4.8.	PSTM COLD – Cold Start	24
4.8.1.	Input Message	24
4.9.	PSTM WARM – Warm Start.....	25
4.9.1.	Input Message	25
4.10.	PSTM HOT – Hot Start	25
4.10.1.	Input Message	26
4.11.	PSTM SRR – System Reset	26
4.11.1.	Input Message	26
4.12.	PSTM GPSRESET – GPS Reset.....	26
4.12.1.	Input Message	26
4.13.	PSTM SBASONOFF – Enable/Disable SBAS.....	26
4.13.1.	Input Message	26
4.14.	PSTM SETCONSTMASK – Set GNSS Constellation Mask	27
4.14.1.	Input Message	27
4.14.2.	Output Message	27
4.15.	PSTM FORCESTANDBY – Force Standby.....	27
4.15.1.	Input Message	28
4.15.2.	Output Message	28
5.	APPENDIX A – STANDARD NMEA MESSAGES FORMAT.....	29
6.	APPENDIX B – SATELLITE ID MAPPING.....	30
7.	GLOSSARY AND ACRONYMS	31

TABLES

Table 1	GGA – Global Positioning System Fix Data Message Structure.....	14
Table 2	GSA – GNSS DOP and Active Satellites Message Structure.....	15
Table 3	GSV – GNSS Satellites in View Message Structure.....	17
Table 4	RMC – Recommended Minimum Specific GNSS Data Message Structure.....	18
Table 5	PSTMGETSWVER – Poll SW Version.....	19
Table 6	PSTMINITGPS – GPS Initialize Message Structure.....	20
Table 7	PSTMINITTIME – Time Initialize Message Structure.....	21
Table 8	PSTMEPHEM – Load Ephemeris Message Structure.....	23
Table 9	PSTMNMEAONOFF – Enable/Disable NMEA Message Structure.....	24
Table 10	PSTMFCOLD – Cold Start Message Structure.....	25
Table 11	PSTMSETCONSTMASK – Set GNSS Constellation Mask.....	27
Table 12	Satellite ID Mapping.....	30

DRAFT

1. INTRODUCTION

1.1. Scope

This document describes the serial communication interface for GNSS receiver modules which operate using V34 firmware. These modules support navigation using the Indian Regional Navigation Satellite System (IRNSS), which is also known by the operational name NavIC.

1.2. Audience

This document is intended for public distribution to potential customers who are evaluating one of the GNSS modules listed in the Applicability Table on page 4, which uses V34 firmware. It can also be used by customers who are developing application software for a Host Processor contained within their product that incorporates one of the listed modules.

1.3. Contact Information, Support

For general contact, technical support services, technical questions and report documentation errors contact Telit Technical Support at:

- TS-EMEA@telit.com
- TS-AMERICAS@telit.com
- TS-APAC@telit.com

Alternatively, use:

<http://www.telit.com/support-training>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<http://www.telit.com>

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.

1.4. Text Conventions



Danger – This information **MUST** be followed or catastrophic equipment failure or bodily injury may occur.



Caution or Warning – Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.



Tip or Information – Provides advice and suggestions that may be useful when integrating the module.

All dates are in ISO 8601 format, i.e. YYYY-MM-DD.

DRAFT

1.5. Related Documents

- [1] NMEA-0183 Standard for Interfacing Marine Electronic Devices Version 3.01
- [2] Telit SL869T3-I Product User Guide Rev.0, 1VV0301546

DRAFT

2. COMMUNICATION INTERFACE

The serial communication interface between the GNSS receiver module and the host processor is based on the NMEA-0183 protocol standard specified by the National Marine Electronics Association (NMEA). This is an ASCII-based standard that is widely used in the GPS industry for serial communication with GNSS receivers **Error! Reference source not found.**



This document does not describe the NMEA 0183 standard, however an overview of NMEA messages format is provided in **Appendix A – Standard NMEA Messages Format**.

This document makes use of STMicroelectronics specific terminology which may differ from the one used in the NMEA-0183 protocol standard specification.

2.1. Serial Communication

Serial communication with the GNSS receiver is primarily conducted over the serial port. There is no hardware flow control. The default port settings are:

- 9600 Baud
- Eight data bits
- No parity bits
- One stop bit

Note that some Firmware versions may have a different default data rate than 9600 baud.

2.2. Talker ID

Standard sentences as defined in the NMEA-0183 protocol begin the "\$" character followed by an NMEA talker ID. Version 3.01 of the protocol defines "GP" as the talker ID for GPS, "GL" as the talker ID for GLONASS, and "GN" as the talker ID indicating a span of multiple global navigation satellite systems (GNSS). Additionally, the V34 firmware has incorporated talker IDs for the other constellations into the standard message format. These talker IDs are "BD" indicating BEIDOU, "GA" indicating GALILEO, QZ for Quasi-Zenith Satellite System (QZSS), and "IR" indicating NavIC/IRNSS.

2.3. Proprietary NMEA Message Format

In addition to the use of standard NMEA sentences, GNSS receiver modules that use V34 firmware communicate with the host processor using STMicroelectronics proprietary messages.

These messages start with the "\$" character, which is then followed by the proprietary address field string that uses the Manufacturer's Mnemonic Code registered by STMicroelectronics with the NMEA, which is "STM". Thus, the proprietary address field is of the form:

`$PSTMxxx`

where xxx represents a Sentence Identifier. The couple Talker ID-Sentence ID (PSTMXXX) is typically referred to as Message Header.

The maximum sentence length for STMicroelectronics proprietary NMEA messages may be greater than the one defined by the NMEA 0183 standard (82 characters).

Chapter 4 of this document describes STMicroelectronics Proprietary NMEA Messages that can be used to control the receiver and output extra information beyond the NMEA-0183 standard definition.

DRAFT

3. NMEA OUTPUT MESSAGES

V34 firmware outputs a set of standard NMEA messages which have formats that are compatible with the NMEA sentences in version 3.01 of the NMEA-0183 Interface Standard. The set of standard NMEA messages are described in section 3.1 below.

3.1. Standard NMEA Output Messages

The standard NMEA messages described below are output once per second. Note that there can be multiple GSA and GSV messages output each second when multiple constellations are being used.

3.1.1. GGA – Global Positioning System Fix Data

This message provides time, position, and fix status data. If the module is using a single constellation, the talker ID reflects that constellation. If the module is operating in multi-constellation mode, the talker ID is 'GN', and the HDOP value in the message is for the combined GNSS constellation geometry.

An example of this message is:

```
$GPGGA,002153.000,3342.6618,N,11751.3858,W,1,10,1.2,27.0,M,-34.2,M,,*5E <CR><LF>
```

Field	Example	Description
Talker ID	GP	Navigation System GP = GPS GL = GLONASS BD = BEIDOU GA = GALILEO IR = IRNSS/NavIC GN = Global Navigation/Multi-constellation
Sentence ID	GGA	Global Positioning System Fix Data
UTC Time	002153.000	hhmmss.sss (hours,minutes,seconds)
Latitude	3342.6618	ddmm.mmmm (degrees and minutes)
N/S Indicator	N	N = North, S = South
Longitude	11751.3858	dddmm.mmmm (degrees and minutes)
E/W Indicator	W	E = East, W = West
Position Fix Indicator	1	0 = Fix not available or invalid 1 = GPS Standard Positioning Service (SPS) Mode, fix valid 2 = Differential GPS (DGPS) SPS Mode, fix valid
Satellites Used	10	Total number of satellites in use in fix
HDOP	1.2	Horizontal Dilution of Precision
MSL Altitude	27.0	Antenna altitude above/below Mean Sea Level (MSL) geoid surface
Units	M	M = Meters

Geoidal Separation	-34.2	Geoid-to-ellipsoid separation Ellipsoid altitude: Geoid MSL altitude – Geoid Separation
Units	M	M = Meters
Age of Differential Data		Null field
Diff. Ref. Station ID		Null field

Table 1 GGA – Global Positioning System Fix Data Message Structure



A valid status is derived from all the parameters set in the software. This includes the minimum number of satellites required, any DOP mask setting and the presence of DGPS corrections. If a required factor is not met, the solution is marked as invalid.

3.1.2. GSA – GNSS DOP and Active Satellites

This message provides GNSS operating mode information, identifies the satellites used in the navigation solution, and reports Dilution of Precision (DOP) values. One GSA message is output for each enabled satellite constellation. See Appendix B regarding the range of satellite IDs used for each constellation.

If the module is using a single constellation, the talker ID reflects that constellation. If the module is operating in multi-constellation mode, the talker ID is 'GN', and all the messages contain DOP values for the combined GNSS constellation geometry.

The maximum number of satellites reported in a single message is 12. If the number of satellites used from a given constellation exceeds 12, a second message is output listing the additional satellites.

An example of this message is:

```
$GNGSA,A,3,07,02,26,27,09,04,15,,,,,1.8,1.0,1.5*2D<CR><LF>
```

Field	Example	Description
Talker ID	GN	Navigation System GP = GPS GL = GLONASS BD = BEIDOU GA = GALILEO GN = Global Navigation/Multi-constellation
Sentence ID	GSA	GNSS DOP and Active Satellites
Mode 1	A	A = Automatic, allowed to automatically switch 2D/3D

Mode 2	3	1 = Fix not available 2 = 2D (<4SV s used) 3 = 3D (>3 SV s used)
Satellite Used [1]	07	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [2]	02	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [3]	26	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [4]	27	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [5]	09	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [6]	04	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [7]	15	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [8]	-	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [9]	-	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [10]	-	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [11]	-	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
Satellite Used [12]	-	Satellite ID used in the solution – Range varies by constellation (see Appendix B – Satellite ID Mapping)
PDOP	1.8	Position Dilution of Precision
HDOP	1.0	Horizontal Dilution of Precision
VDOP	1.5	Vertical Dilution of Precision

Table 2 GSA – GNSS DOP and Active Satellites Message Structure

3.1.3. GSV – GNSS Satellites in View

This message provides the number of Space Vehicle (SV) satellites in view, and the elevation, azimuth and Signal to Noise (SNR) values for all satellites in view. A message is output each second for each enabled constellation, and each message can consist of multiple sentences, with four satellites maximum per sentence. The talker ID of the message always reflects the constellation for which the visible satellite information as being reported.

An example of messages reporting the GPS satellites in view is:

```
$GPGSV,2,1,07,07,79,048,42,02,51,062,43,26,36,256,42,27,27,138,42*71<CR><LF>
$GPGSV,2,2,07,09,23,313,42,04,19,159,41,15,12,041,42*41<CR><LF>
```

An example of messages reporting the NavIC (IRNSS) satellites in view is:

```
$IRGSV,2,1,07,805,62,070,44,803,56,174,44,804,46,112,44,801,39,213,44*7A
$IRGSV,2,2,07,806,28,247,44,807,25,111,44,802,14,206,44,,,,,*75
```

Field	Example	Description
Talker ID	GP	Navigation System GP = GPS GL = GLONASS BD = BEIDOU GA = GALILEO QZ = QZSS GN = Global Navigation/Multi-constellation
Sentence ID	GSV	GNSS Satellites in View
Number of Messages	2	Total number of GSV messages to be sent in this group
Message Number	1	Message number in this group of GSV messages
Satellite in View	07	Total number of satellites in view
Satellite ID1	07	Range varies by constellation (see Appendix B – Satellite ID Mapping)
Elevation1	79	Elevation angle in degrees, 0-90
Azimuth1	048	Azimuth angle in degrees, True, 000-359 clockwise from true North
SNR1	42	SNR (C/No), 00-99 dB-Hz, null while not tracking
Satellite ID2	02	Range varies by constellation (see Appendix B – Satellite ID Mapping)
Elevation2	51	Elevation angle in degrees, 0-90
Azimuth2	062	Azimuth angle in degrees, True, 000-359 clockwise from true North
SNR2	43	SNR (C/No), 00-99 dB-Hz, null while not tracking
Satellite ID3	26	Range varies by constellation (see Appendix B – Satellite ID Mapping)
Elevation3	36	Elevation angle in degrees, 0-90
Azimuth3	256	Azimuth angle in degrees, True, 000-359 clockwise from true North
SNR3	42	SNR (C/No), 00-99 dB-Hz, null while not tracking

Satellite ID4	27	Range varies by constellation (see Appendix B – Satellite ID Mapping)
Elevation4	27	Elevation angle in degrees, 0-90
Azimuth4	138	Azimuth angle in degrees, True, 000-359 clockwise from true North
SNR4	42	SNR (C/No), 00-99 dB-Hz, null while not tracking

Table 3 GSV – GNSS Satellites in View Message Structure

3.1.4. RMC – Recommended Minimum Specific GNSS Data

This message provides time, date, position, course and speed data from navigational fixes made by the GNSS receiver module. If the module is using a single constellation, the talker ID reflects that constellation. If the module is operating in multi-constellation mode, the talker ID is 'GN'.

An example of this message is:

```
$GPRMC,161229.487,A,3723.2475,N,12158.3416,W,0.13,309.62,120598,,A*7D<CR><LF>
```

Field	Example	Description
Talker ID	GP	Navigation System GP = GPS GL = GLONASS BD = BEIDOU GA = GALILEO GN = Global Navigation/Multi-constellation
Sentence ID	RMC	Recommended Minimum Specific GNSS Data
UTC Time	161229.487	hhmmss.sss (hours,minutes,seconds)
Status	A	A = Data valid V = Data not valid
Latitude	3723.2475	ddmm.mmmm (degrees and minutes)
N/S Indicator	N	N = North, S = South
Longitude	12158.3416	dddmm.mmmm (degrees and minutes)
E/W Indicator	W	E = East, W = West
Speed Over Groud	0.13	Knots
Course Over Ground	309.62	True, degrees
Date	120598	ddmmyy (day, month, year)
Magnetic Variation		Null field
Magnetic E/W Indicator		Null field

Mode	A	A = Autonomous mode D = Differential mode N = Data not valid
------	---	--

Table 4 RMC – Recommended Minimum Specific GNSS Data Message Structure

DRAFT

4. Proprietary NMEA MESSAGES

4.1. PSTMGETSWVER – Poll SW Version

The PSTMGETSWVER command is used to poll the firmware version information. Version information includes the Telit firmware version string, as well as versions of the ST Microelectronics libraries embedded within the firmware application.

4.1.1. Input Message

Synopsis:

```
$PSTMGETSWVER,<Id><CR><LF>
```

Example:

```
$PSTMGETSWVER,255<CR><LF>
```

Parameter	Format	Description
Message Header	PSTMGETSWVER	Poll SW Version
Mask	255	Integer 0 – GNSS Library 1 – Operating Kernel 2 – Application Layer (SDK) 8 – STAGPS Library 255 – All version strings

Table 5 PSTMGETSWVER – Poll SW Version

4.1.2. Output Message

If the command is successful, the module responds with the requested firmware version string(s). The Telit version string is reported in a standard NMEA GPTXT message as shown in the example below:

```
$GPTXT,Telit V34-0.0.1-NVC-4.X.11A5-N115-A01V*60
```

ST Microelectronics component version information is reported in a proprietary NMEA sentence, as illustrated below:

```
$PSTMVER,GNSSLIB_8.4.13.20.10_EB_ARM*32
```

4.2. PSTMINITGPS – GPS Initialize

The PSTMINITGPS command is used to initialize position and GPS time in the receiver module. It is typically only used for test purposes or for aiding satellite acquisitions in very harsh RF signal environments.

4.2.1. Input Message

Synopsis:

```
$PSTMINITGPS,<Lat>,<LatRef>,<Lon>,<LonRef>,<Alt>,<Day>,<Month>,<Year>,<Hour>,<Minute>,<Second><CR><LF>
```

Example:

```
$PSTMINITGPS,4811.365,N,01154.123,E,0530,23,02,2018,09,44,12
```

Field	Example	Description
Message Header	PSTMINITGPS	GPS Initialize
Lat	4811.365	Latitude - DDMM.MMM (DegreesMinutes.FractionalMinute)
LatRef	N	Latitude direction - 'N' or 'S' (North or South)
Lon	01154.123	Longitude - DDDMM.MMM (DegreesMinutes.FractionalMinute)
LonRef	E	Longitude direction - 'E' or 'W' (East or West)
Alt	0530	WGS-84 altitude in meters - dddd – Decimal, 4 digits (-1500 to 100000)
Day	23	Day of month - dd – Decimal, 2 digits (01 to 31)
Month	02	Month - mm – Decimal, 2 digits (01 to 12)
Year	2018	Year - yyyy – Decimal, 4 digits (1994 - ...)
Hour	09	Hour - HH – Decimal, 2 digits (00 to 23)
Minute	44	Minute - MM – Decimal, 2 digits (00 to 59)
Second	12	Second - SS – Decimal, 2 digits (00 to 59)

Table 6 PSTMINITGPS – GPS Initialize Message Structure



The provided date must be no earlier than September 3rd, 2017. Date/time data will be ignored by the module if it already has an estimate of time. Likewise, the position data will be ignored by the module if it already has an estimate position. If the data is accepted, it will be reflected in the output messages, for example \$GPGGA.

4.2.2. Output Message

Synopsis:

```
$PSTMINITGPSOK<CR><LF>
```

The \$PSTMINITGPS command is ignored by the module if any of the input parameters are out of range or if the command is otherwise formatted incorrectly, and the module will respond with the message:

```
$PSTMINITGPSError*1C<CR><LF>
```

4.3. PSTMINITIME – Time Initialize

The PSTMINITIME command may be used to initialize GPS time in the receiver. It is typically only used for test purposes or for aiding satellite acquisitions in very harsh RF signal environments.

4.3.1. Input Message

Synopsis:

`$PSTMINITIME,<Day>,<Month>,<Year>,<Hour>,<Minute>,<Second><CR><LF>`

Example:

`$PSTMINITIME,23,02,2018,09,44,12`

Field	Example	Description
Message Header	PSTMINITIME	Time Initialize
Day	23	Day of month - dd – Decimal, 2 digits (01 to 31)
Month	02	Month - mm – Decimal, 2 digits (01 to 12)
Year	2018	Year - yyyy – Decimal, 4 digits (1994 - ...)
Hour	09	Hour - HH – Decimal, 2 digits (00 to 23)
Minute	44	Minute - MM – Decimal, 2 digits (00 to 59)
Second	12	Second - SS – Decimal, 2 digits (00 to 59)

Table 7 *PSTMINITIME – Time Initialize Message Structure*



The provided date must be no earlier than September 3rd, 2017. The input time will be ignored by the module if it already has an estimate of time. If the data is accepted, it will be reflected in the output messages, for example \$GPGGA.

4.3.2. Output Message

`$PSTMINITIMEOK*11<CR><LF>`

The \$PSTMINITIME command is ignored by the module if any of the input parameters are out of range or if the command is otherwise formatted incorrectly, and the module will respond with the message:

`$PSTMINITIMEERROR*4D<CR><LF>`

4.4. PSTMCLREPHS – Clear Ephemeris

The PSTMCLREPHS command allows the user to clear all ephemeris data from battery-backed RAM and erase all ephemeris stored in non-volatile backup memory. It is typically used to force the module to collect the most recent satellite ephemeris data, or to prepare the module to be loaded with ephemeris data over the serial port. There are no parameters, and there is no response message to this command.

4.4.1. Input Message

Synopsis:

```
$PSTMCLREPHS<CR><LF>
```

Following an ephemeris data deletion, the module stops producing position fixes using tracked satellites for which it had ephemeris. Note however that this command does not clear predicted ephemeris associated with the STAGPS feature. Thus, if the module had been navigating using predicted ephemeris for a tracked satellite (because broadcast ephemeris had not yet been collected), then the module continues to use that satellite.

Typically, the module falls out of navigation after the execution of an \$PSTMCLREPHS command due to an insufficient number of satellites used. The module will produce position fixes after it has re-collected ephemeris from a sufficient number of satellites.

4.5. PSTMDUMPEPHEMS – Dump Ephemeris

The PSTMDUMPEPHEMS command is used to request that the module outputs all ephemeris data stored in backup memory. There are no parameters.

4.5.1. Input Message

Synopsis:

```
$PSTMDUMPEPHEMS<CR><LF>
```

The module responds with a series of \$PSTMEPHEM messages, each containing the ephemeris data for one satellite. Each of these messages has the same format as the \$PSTMEPHEM command described in the next section. Checksums are included in \$PSTMEPHEM when it is a message, but they are not required when \$PSTMEPHEM is used as a command.

The module echoes the command once all the response messages have been output.



The \$PSTMEPHEM response messages do not block regularly scheduled periodic output messages, and therefore they are not guaranteed to be output all in sequence. The \$PSTMNMEAONOFF command can be used to temporarily disable periodic output so that the response messages can be captured as one sequence and then be re-used as a source of \$PSTMEPHEM load ephemeris commands.

4.6. PSTMEPHEM – Load Ephemeris

The PSTMEPHEM command allows the user to load ephemeris data for a satellite into battery-backed RAM and non-volatile backup memory. It has the same ID and data structure as when it is output as a message.

4.6.1. Input Message

Synopsis:

```
$PSTMEPHEM,<SatId>,<Size>,<Byte1>.....<ByteN>*<checksum><CR><LF>
```

Example:

```
$PSTMEPHEM,3,64,8f06786978691313132001009ba4ff009af9e5178c12aafaba006e00fc3700001f7eea25cab5b60780b00da183d906cb6048efd545e6e12ff7002d0012c0c003
```

Field	Example	Description
Message Header	PSTMEPHEM	Load Ephemeris
SatId	3	Satellite ID - ii – Decimal, 2 digits (GPS PRN number, range 1 to 32)
Size	64	Number of ephemeris data bytes in the command - nn - Decimal, 2 digits
Byte1... ByteN	8f06786978691 313132001009b a4ff009af9e517 8c12aafaba006e 00fc3700001f7e ea25cab5b6078 0b00da183d906 cb6048efd545e6 e12ff7002d0012 c0c003	N ephemeris data bytes - bb – Hexadecimal, 2 digits

Table 8 PSTMEPHEM – Load Ephemeris Message Structure

Note also that the ephemeris data bytes are input as a single parameter and are not delimited by commas.

4.6.2. Output Message

If the command is successful, the module responds with the message:

```
$PSTMEPHEMOK*48
```

If the module detects a problem with data, for example an insufficient number of data bytes, and the command fails to execute, the module responds with the message:

```
$PSTMEPHEMERROR*17
```



This command has the same format as the \$PSTMEPHEM message that is output in response to the \$PSTMDUMPEPHEMS command described in the previous section.

4.7. PSTMNMEAONOFF – Enable/Disable NMEA

The PSTMNMEAONOFF command can be used to switch the periodic NMEA output on and off. It does not affect command responses. The parameter is optional. If the parameter is not provided, the NMEA output is toggled on or off. There is no response message to this command.

4.7.1. Input Message

Synopsis:

```
$PSTMNMEAONOFF[,<OnOff>]<CR><LF>
```

Example:

```
$PSTMNMEAONOFF,0
```

Field	Example	Description
Message Header	PSTMNMEAON OFF	Enable/Disable NMEA
OnOff	0	One-digit decimal 0 – NMEA output will be disabled 1 – NMEA output will be enabled

Table 9 *PSTMNMEAONOFF – Enable/Disable NMEA Message Structure*

4.8. PSTMCOLD – Cold Start

The PSTMCOLD command can be used to cause the module to perform a cold start. There is no response message to this command.

4.8.1. Input Message

Synopsis:

```
$PSTMCOLD,[<Mask>]<CR><LF>
```

Example:

```
$PSTMCOLD,15<CR><LF>
```


Parameter	Format	Description
Message Header	PSTMCOLD	Cold Start
Mask	15	Optional configuration parameter in the form of a bit mask expressed as an integer. It is used to specify data to be invalidated for the cold start. Bit definitions: bit 0 – clear almanac bit 1 – clear ephemeris bit 2 – clear position bit 3 – clear time

Table 10 PSTMCOLD – Cold Start Message Structure

If the mask parameter is not provided, the default cold start configuration, bitmap 0xE (clear ephemeris, position and time), is used. This is equivalent to an input parameter of 14 and is the most common definition of a cold start used in the industry.

In response to this message the module will restart the GNSS engine.



The PSTMCOLD command does not necessarily replicate an operational cold start, which occurs when the module is powered up from an off state (both main power and Vbatt are removed). In this case the module uses stored position, time, date and ephemeris from non-volatile memory as its initial data.

4.9. PSTMWARM – Warm Start

The PSTMWARM command causes the module to perform a warm start. A warm start is defined as one in which position and time are known from previous operation of the GNSS module, but ephemeris is invalid. There are no parameters, and there is no response message to this command.

4.9.1. Input Message

Synopsis:

```
$PSTMWARM<CR><LF>
```

In response to this message the module will restart the GNSS engine.

4.10. PSTMHOT – Hot Start

The PSTMHOT command causes the module to perform a hot start. A hot start is defined as one in which position and time are known and ephemeris is valid from previous operation of the GNSS module. There are no parameters, and there is no response message to this command.

4.10.1. Input Message

Synopsis:

```
$PSTMHOT<CR><LF>
```

In response to this message the module will restart the GNSS engine.

4.11. PSTMSRR – System Reset

The PSTMSRR command allows the user to execute a system reset and reboot the GNSS firmware on the module. There are no parameters, and there is no response message to this command.

4.11.1. Input Message

Synopsis:

```
$PSTMSRR<CR><LF>
```



The module does not echo the \$PSTMSRR command.

4.12. PSTMGPSRESET – GPS Reset

The PSTMGPSRESET command is used to restart the GNSS receiver engine without rebooting the GNSS module firmware. There are no parameters for this command, and there is no response message to this command.

4.12.1. Input Message

Synopsis:

```
$PSTMGPSRESET<CR><LF>
```

4.13. PSTMSBASONOFF – Enable/Disable SBAS

The PSTMSBASONOFF command can be used to toggle the SBAS differential GPS feature on and off. By default, the SBAS feature is on (enabled) whenever the module is reset. When SBAS is on (enabled), the module searches for SBAS satellites based on its position. If the module successfully acquires a satellite, it obtains and uses differential GPS corrections transmitted by the satellite. The satellite ID of the acquired SBAS satellite appears in the GPGSV messages. For SBAS satellites, the ID is the satellite PRN minus an offset of 87.

4.13.1. Input Message

Synopsis:

```
$PSTMSBASONOFF<CR><LF>
```

There is no response message associated with this command.

4.14. PSTMSETCONSTMASK – Set GNSS Constellation Mask

The PSTMSETCONSTMASK command selects the GNSS constellations to be used by the GNSS module for navigation. The selected constellations are specified using a bit mask.

4.14.1. Input Message

Synopsis:

```
$PSTMSETCONSTMASK,<Constellation_Mask><CR><LF>
```

Example:

```
$PSTMSETCONSTMASK,1025<CR><LF>
```

Parameter	Format	Description
Message Header	PSTMSETCONSTMASK	Set GNSS Constellation Mask
Constellation_Mask	1025	Bit mask expressed as an integer, where each bit is used to enable/disable a specific constellation independently. bit 0 – GPS bit 1 – GLONASS bit 2 – QZSS bit 3 – GALILEO bit 7 – BEIDOU bit 10 – NavIC (IRNSS) Other bits are reserved and should be set to 0.

Table 11 *PSTMSETCONSTMASK – Set GNSS Constellation Mask*

4.14.2. Output Message

If the command is successful, the module responds with a message echoing the specified mask, and the new constellation mask remains in effect until a system reset is performed on the module:

```
$PSTMSETCONSTMASKOK,<Constellation_Mask>*<checksum><CR><LF>
```

If the input parameter for the command is missing or is not a valid value, the module responds with the following message:

```
$PSTMSETCONSTMASKERROR*51<CR><LF>
```

4.15. PSTMFORCESTANDBY – Force Standby

The PSTMFORCESTANDBY command is used to put the module in a very low power Standby state for a specified length of time. After the specified time has elapsed, the module returns to its previous operational mode.

4.15.1. Input Message

Synopsis:

```
$PSTMFORCESTANDBY,<Duration><CR><LF>
```

where Duration is an unsigned integer value specifying the Standby mode time period in seconds, ranging from 1 to 65535 seconds (~18.2 hours).

4.15.2. Output Message

If the command is successful, the module responds with the following message and enters Standby mode:

```
$PSTMFORCESTANDBYOK*14<CR><LF>
```

If the input parameter is missing or contains invalid characters, the module responds with the following message:

```
$PSTMFORCESTANDBYERROR*48<CR><LF>
```

Caution



1. If the command is successful, note that the module could enter Standby mode before issuing the OK response message and/or command echo.
 2. Numerical command parameter values outside the specified range should be avoided.
-

5. APPENDIX A – STANDARD NMEA MESSAGES FORMAT

Serial communication between the Host Processor and the GNSS module is accomplished using messages following the NMEA 0183 standard. Standard NMEA messages output by the receiver are called “Sentences” and always start with an ASCII ‘\$’ character (Hex value 0x24). All NMEA sentences also end or terminate with a two-character Carriage Return <CR> (ASCII hex value 0x0D) Line Feed <LF> (ASCII hex value 0xA) sequence.

After the starting ‘\$’ character a NMEA sentence contains a two-character Talker Identifier which may have the values GP for GPS, IR for NAVIC (IRNSS) or GN for Global Navigation that can be a combination of the individual navigation system (GPS, NAVIC). The Talker Identifier indicates the GNSS system source of the information contained in the sentence. Following the Talker Identifier is a three-character Sentence Identifier. The Sentence Identifier indicates the type of the sentence. Each type is described in its own section in this document.

Following the Sentence Identifier is a sequence of Data Fields that are separated, or delimited, by commas. The number and meaning of the data fields, which are sometimes referred to as the Payload of the sentence, is determined by the sentence type. A specific data field might be omitted from a sentence and then that field is called a NULL field. A NULL field is still separated from the other fields by commas.

After the last data field appears, the ‘*’ character (ASCII hex value 0x2A) denotes the end of the data fields. Immediately following the ‘*’ character is a two-character hexadecimal checksum used to detect errors in the sentence that might have been introduced during serial transmission. The NMEA sentence checksum is computed by performing an 8-bit Exclusive OR (XOR) sum on all the characters in the sentence that appear after the ‘\$’ character and before the ‘*’ character.

After the checksum appears the terminating <CR><LF> sequence.

The maximum length of a NMEA standard sentence is 82 characters, consisting of a maximum of 79 characters in the string between the starting ‘\$’ character and the terminating <CR><LF>.

6. APPENDIX B – SATELLITE ID MAPPING

SATELLITE ID MAPPING

Value	Constellation	Description
1 to 32	GPS	PRN
33 to 51	SBAS	PRN - 87
65 to 92	GLONASS	Slot ID + 64
141 to 172	BEIDOU	PRN + 140
193 to 199	QZSS	PRN
301 to 330	Galileo	PRN + 300
801 to 807	NAVIC (IRNSS)	PRN + 800

Table 12 Satellite ID Mapping

7. GLOSSARY AND ACRONYMS

ASCII	American Standard Code for Information Interchange
BE	Broadcast Ephemeris
DGPS	Differential Global Positioning System
DOP	Dilution of Precision
NMEA	National Marine Electronics Association
PRN	Pseudo-Random Noise
SRAM	Static Random Access Memory
STAGPS	ST Assisted GPS
UTC	Co-ordinated Universal Time

DRAFT

8. DOCUMENT HISTORY

Revision	Date	Changes
0	2018-11-16	Marketing draft

DRAFT



SUPPORT INQUIRIES

Link to www.telit.com and contact our technical support team for any questions related to technical issues.

www.telit.com



Telit Communications S.p.A.
Via Stazione di Prosecco, 5/B
I-34010 Sgonico (Trieste), Italy

Telit Wireless Solutions Inc.
3131 RDU Center Drive, Suite 135
Morrisville, NC 27560, USA

Telit Wireless Solutions Ltd.
10 Habarzel St.
Tel Aviv 69710, Israel

Telit IoT Platforms LLC
5300 Broken Sound Blvd, Suite 150
Boca Raton, FL 33487, USA

Telit Wireless Solutions Co., Ltd.
8th Fl., Shinyoung Securities Bld.
6, Gukjegeumyung-ro8-gil, Yeongdeungpo-gu
Seoul, 150-884, Korea

Telit Wireless Solutions
Tecnologia e Servicos Ltda
Avenida Paulista, 1776, Room 10.C
01310-921 São Paulo, Brazil

Telit reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. The information contained herein is provided "as is". No warranty of any kind, either express or implied, is made in relation to the accuracy, reliability, fitness for a particular purpose or content of this document. This document may be revised by Telit at any time. For most recent documents, please visit www.telit.com

Copyright © 2016, Telit