



Cat M/NB-IoT Quick Start Guide

80529NT11661A Rev. 3 – 2020-07-22

TELIT
TECHNICAL
DOCUMENTATION

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

NOTICE

While reasonable efforts have been made to assure the accuracy of this document, Telit assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. The information in this document has been carefully checked and is believed to be reliable. However, no responsibility is assumed for inaccuracies or omissions. Telit reserves the right to make changes to any products described herein and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Telit does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others.

It is possible that this publication may contain references to, or information about Telit products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Telit intends to announce such Telit products, programming, or services in your country.

COPYRIGHTS

This instruction manual and the Telit products described in this instruction manual may be, include or describe copyrighted Telit material, such as computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Telit and its licensors contained herein or in the Telit products described in this instruction manual may not be copied, reproduced, distributed, merged or modified in any manner without the express written permission of Telit. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit, as arises by operation of law in the sale of a product.

COMPUTER SOFTWARE COPYRIGHTS

The Telit and 3rd Party supplied Software (SW) products described in this instruction manual may include copyrighted Telit and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the Italy and other countries preserve for Telit and other 3rd Party supplied SW certain exclusive rights for copyrighted computer programs, including the exclusive right to copy or reproduce in any form the copyrighted computer program. Accordingly, any copyrighted Telit or other 3rd Party supplied SW computer programs contained in the Telit products described in this instruction manual may not be copied (reverse engineered) or reproduced in any manner without the express written permission of Telit or the 3rd Party SW supplier. Furthermore, the purchase of Telit products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Telit or other 3rd Party supplied SW, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

USAGE AND DISCLOSURE RESTRICTIONS

I. License Agreements

The software described in this document is the property of Telit and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

II. Copyrighted Materials

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Telit

III. High Risk Materials

Components, units, or third-party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities"). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

IV. Trademarks

TELIT and the Stylized T Logo are registered in Trademark Office. All other product or service names are the property of their respective owners.

V. Third Party Rights

The software may include Third Party Right software. In this case you agree to comply with all terms and conditions imposed on you in respect of such separate software. In addition to Third Party Terms, the disclaimer of warranty and limitation of liability provisions in this License shall apply to the Third Party Right software.

TELIT HEREBY DISCLAIMS ANY AND ALL WARRANTIES EXPRESS OR IMPLIED FROM ANY THIRD PARTIES REGARDING ANY SEPARATE FILES, ANY THIRD PARTY MATERIALS INCLUDED IN THE SOFTWARE, ANY THIRD PARTY MATERIALS FROM WHICH THE SOFTWARE IS DERIVED (COLLECTIVELY "OTHER CODE"), AND THE USE OF ANY OR ALL THE OTHER CODE IN CONNECTION WITH THE SOFTWARE, INCLUDING (WITHOUT LIMITATION) ANY WARRANTIES OF SATISFACTORY QUALITY OR FITNESS FOR A PARTICULAR PURPOSE.

NO THIRD PARTY LICENSORS OF OTHER CODE SHALL HAVE ANY LIABILITY FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST PROFITS), HOWEVER CAUSED AND WHETHER MADE UNDER CONTRACT, TORT OR OTHER LEGAL THEORY, ARISING IN ANY WAY OUT OF THE USE OR DISTRIBUTION OF THE OTHER CODE OR THE EXERCISE OF ANY RIGHTS GRANTED UNDER EITHER OR BOTH THIS LICENSE AND THE LEGAL TERMS APPLICABLE TO ANY SEPARATE FILES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

APPLICABILITY TABLE

PRODUCTS

- ■ ME910C1 SERIES
- ■ ME910G1 SERIES
- ■ ML865C1 SERIES
- ■ ML865G1 SERIES
- ■ ME310G1 SERIES

CONTENTS

1	INTRODUCTION	6
1.1	Scope	6
1.2	Audience	6
1.3	Contact Information, Support	6
1.4	Related Documents	6
2	GENERAL DESCRIPTION.....	7
2.1	ME910C1, ML865C1 Main Features.....	7
2.2	ME910G1, ML865G1,ME310G1 Main Features	8
2.3	USB/UART port configuration	9
2.4	Warning on Windows Cellular connection.....	10
3	APPLICATION MAIN FLOW.....	11
4	NETWORK REGISTRATION	12
4.1	CAT-M1 / NB-IoT Registration AT script example	12
4.2	2G Registration AT script example	14
4.3	Access technology selection.....	15
4.4	Speed up registration.....	16
5	CHECK/SET DATA SERVICE	17
6	UDP SCRIPT.....	18
7	TCP SCRIPT	20
8	PSM AND EDRX	22
8.1	PSM/eDRX overview	22
8.2	PSM script.....	23
8.3	eDRX script	27
8.4	PSM in between eDRX script.....	30
8	Document History.....	32

1 Introduction

1.1 Scope

Scope of this document is to give an overview and basic instructions of how to start using the following product series: ME910C1, ME910G1, ML865C1, ML865G1, ME310G1.

1.2 Audience

This document is intended for customers who want to use and test the NE866 product.

1.3 Contact Information, Support

For general contact, technical support services, technical questions and report documentation errors contact Telit Technical Support at:

TS-EMEA@telit.com

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<http://www.telit.com>

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.

1.4 Related Documents

- 1VV0301351 ME910C1 HW User Guide Rev.12
- 1VV0301588 ME310G1 Hardware Design Guide Rev. 5
- 80529ST10815A ME910C1/NE910C1/ML865C1 AT Commands Reference Guide Rev. 12
- 80617ST10991A ME310G1/ME910G1/ML865G1 AT Commands Reference Guide Rev. 5
- 80529NT11643A ME910C1/NE910C1/ML865C1 PSM Application Note Rev. 1
- 80617NT11830A ME310G1/ME910G1/ML865G1 PSM Application Note Rev. 0

2 General Description

2.1 ME910C1, ML865C1 Main Features

- LTE UE Category M1/NB1 3GPP release 13 compliant
- Half Duplex FDD
- Single Rx, single antenna
- 3GPP Rel. 12 Power Saving Mode (PSM)
- 3GPP Rel. 13 Extended Discontinuous Reception (eDRX)
- 3GPP Rel. 13 Extended coverage
- Control via AT commands according to 3GPP TS27.005, 27.007 and customized AT commands
- SIM application Tool Kit 3GPP TS 51.01
- SMS over NAS
- IPv4/IPv6 stack with TCP and UDP protocol
- OMA Lightweight M2M (LWM2M)
- Firmware Over-the-Air Update (FOTA) using delta upgrade techniques
- Telit Application Development Environment: AppZone C (for future release)
- SSL
- Optional embedded GNSS (GPS, GLONASS, Beidou, Galileo)

2.2 ME910G1, ML865G1,ME310G1 Main Features


- LTE UE Cat M1 (1.4 MHz)/NB2 (200 KHz)
- 3GPP Rel. 14 compliant
- Half-duplex FDD
- Single Rx, single antenna
- 3GPP Rel. 12 PSM
- 3GPP Rel. 13 eDRX
- 3GPP Rel. 13 Extended Coverage
- Control via AT commands according to 3GPP TS 27.005, 27.007 and customized Telit AT commands
- SIM application tool kit 3GPP 51.01
- VoLTE (planned)
- SMS over NAS
- IPv4/IPv6 stack with TCP and UDP protocol
- Firmware Over-the-Air Update (FOTA) using delta upgrade techniques
- TLS/DTLS
- Embedded GNSS (GPS, GLONASS, Beidou, Galileo)
- OMA Lightweight M2M (LwM2M)

2.3 USB/UART port configuration

ME910C1, ME910G1, ML865C1, ML865G1, ME310G1 are equipped with 2 asynchronous serial port (CMOS 1.8) and one integrated universal serial bus (USB 2.0 HS) transceiver with the following composition:

- 2 Telit USB Modem ports
- 1 Telit HS-USB WWAN
- 1 Telit Serial Diagnostic Interface


The screenshot below reports an example of the port composition listed on Windows 10 Device Manager.



USB Modem ports are ACM devices and can be used as AT Command interface.

Telit HS-USB WWAN is an RMNET adapter that can be used with Linux ModemManager and NetworkManager.

On Windows 10 WWAN Adapter should be automatically loaded as Cellular Connection in Network & Internet settings (see image below).



Telit Serial Diagnostic Interface is used for debugging purposes and for firmware upgrade.


2.4 Warning on Windows Cellular connection

When the module is recognized as a Cellular device, Windows uses the WWAN interface to set up internet connection (NCSI). This could lead to connectivity issues using the module AT interface: registration to the network, APN management, socket creation and data exchange, PSM and eDRX functionalities can be affected.

If you do not need your PC is connected via WWAN interface, we strongly suggest to disable it. Go to:

Control Panel ► Network and Sharing Center ► change Adapter settings ► right-click on Cellular connection ► disable.

3 Application Main Flow



4 Network Registration

Here below a brief overview of 4G (CAT M1, NB IoT) and 2G (GPRS) registration process, IP stack setup and related commands.

4G registration (CAT-M1, NB-IoT) and IP stack setup: the module performs Attach and EPS Bearer activation automatically. When the procedure ends an IP address is assigned by the network to the module. AT+CEREG can be used to check the EPS network registration status. AT+CGCONTRDP can be used to check the EPS bearer parameters. AT#SGACT command has to be used to enable the internal IP stack and IPEasy command set.

2G registration and IP stack setup: the module performs GPRS Attach automatically. You can check the status of registration using AT+CREG and AT+CGREG commands. To get IP connectivity the user has to activate a PDP context. In this scenario, AT#SGACT command performs PDP context activation and IP internal stack enabling. After this step, the module has an IP address and IPEasy command set can be used. AT+CGCONTRDP can be used to check the PDP context parameters.

To get IP connectivity, for all access technology, a specific APN configuration is required. We suggest to carefully check with the Network Provider what's the proper APN configuration to be used (context ID, APN name). APN configuration can be set through AT+CGDCONT command.

4.1 CAT-M1 / NB-IoT Registration AT script example

The module is turned on, APN on context 1 is required by MNO for registration and data traffic

```
AT+CEREG?
+CEREG: 0,2
OK
```

```
AT+CGDCONT=1,"IP","nbiot.tids.tim.it"
OK
```

New attach is needed to use the new APN. A way to do this is to turn the radio off and on using AT+CFUN

AT+CFUN=4
OK

AT+CEREG?
+CEREG: 0,0
OK

AT+CFUN=1
OK

AT+CEREG?
+CEREG: 0,0
OK

AT+CEREG?
+CEREG: 0,2
OK

AT+CEREG?
+CEREG: 0,1
OK

AT+COPS?
+COPS: 0,1,"I TIM",9
OK

AT+CGCONTRDP
+CGCONTRDP: 1,5,"nbiot.tids.tim.it","10.16.13.162",,"192.168.200.43","192.168.200.42"
OK

The module is registered and has an IP address (10.16.13.162).

AT#SGACT=1,1
#SGACT: 10.16.13.162
OK

Module IP stack is on, IPEasy commands can be used, e.g. we can open a TCP socket

AT#SD=1,0,80,"www.telit.com"

CONNECT

+++ escape sequence sent here to move on Command Mode

OK

AT#SS
#SS: 1,2,10.16.13.162,36862,35.202.235.194,80
...
OK

4.2 2G Registration AT script example

The module is turned on and attached, APN on context 1 is required by MNO for data traffic

AT+CREG?

+CREG: 0,1

OK

AT+CGREG?

+CGREG: 0,1

OK

AT+CGDCONT=1,"IP","internet.wind.biz"

OK

There's no need to trigger new registration since the APN will be used in the next step: the PDP context activation request

AT#SGACT=1,1

#SGACT: 10.34.234.204

OK

The PDP context is active, IP address has been assigned (10.34.234.204) and IP stack is enabled; now it is possible to perform a socket connection

AT+CGCONTRDP

+CGCONTRDP: 1,5,"internet.wind.biz","10.34.234.204",,"193.70.152.25","212.52.97.25"

OK

AT#SD=1,0,80,"www.telit.com"

CONNECT

+++ escape sequence sent here to move on Command Mode

OK

AT#SS

#SS: 1,3,10.34.234.204,35911,35.202.235.194,80

...

OK

In all scenarios (2G, CAT-M1, NB-IoT) the command AT+CGDCONT stores APN in NVM, so the APN setting is needed only once.

4.3 Access technology selection

AT+WS46=[<n>] command selects the cellular network to operate with.

- 4G/2G products support <n> parameter values 12, 28 and 30. 30 is factory default
- 4G only products support <n> parameter value 28

Values [<n>]:

12 : GSM Digital Cellular Systems, GERAN only

28 : E-UTRAN only

30 : GERAN and E-UTRAN

AT#WS46=[<n>] command selects the IoT E-UTRAN technology to operate with.

Values [<n>]:

0 : CAT-M1

1 : NB-IoT

2 : CAT-M1 (preferred) and NB-IoT

3 : CAT-M1 and NB-IoT (preferred)

The parameter is stored in NVM and the settings is available at next reboot.

4.4 Speed up registration

The registration process in CAT-M1 and NB-IoT technologies could require some minutes to complete. This happens especially in the case of very first registration: new SIM, new location, new module. This is due to the IoT technology itself and cellular network deployment factors.

To speed up the process you can reduce the set of supported technologies and bands. This will reduce the radio scanning time of the module. The example below refers to NB-IoT, the same can be applied to CAT-M1.

1. Check with operator if:
 - a. the SIM you have is enabled for NB-IoT or CAT-M1; the majority of operators provides specific SIM for IoT services and technology
 - b. an APN has to be set for registration/attach and data traffic
2. Turn on the module and set the APN if required, in the majority of cases you'll have to set it on 1st context: e.g. `AT+CGDCONT=1,"IP","NB IoT APN"`
3. Set the module for NB IoT only support: `AT+WS46=28` , `AT#WS46=1`
4. Use `AT#BND` to reduce the set of supported bands. E.g. set support for band 3 and 8 only: `AT#BND=0,0,132` (132 decimal ► 1000 0100 binary)
5. Reboot the module to apply the changes above
6. When the module is back on, wait some seconds and run manual registration through `AT+COPS=1,2,"MCCMNC"`
7. Poll `AT+CEREG?` to check the registration status or enable unsolicited indication through `AT+CEREG=2`

The same will apply for CAT-M1 using `AT#WS46=0`.

The reboot is required only once to apply the `AT#WS46` setting. Subsequent registrations are usually faster (e.g. after power cycle): the module store radio link information about previous registration and use this information to start a new registration.

5 Check/Set data service

When registration is completed you can activate data services and set up the internal IP stack with the AT#SGACT command:

AT#SGACT=<cid>,<stat>[,<userId>[,<pwd>]]

E.g. if we want to activate context 1, issue AT#SGACT=1,1; in case we want to use the <cid> 3 (e.g. Verizon in US) issue AT#SGACT=3,1.

The command returns IP address provided by the network:

AT#SGACT=1,1

#SGACT: xxx.xxx.xxx.xxx

You can get useful information about the active context using AT+CGCONTRDP command.

AT+CGCONTRDP=[<cid>]

The execution command returns the relevant information on a PDP Context – EPS Bearer established by the network with the context identifier <cid>. If the parameter <cid> is omitted, the information for all established contexts is returned. The response message has the following format.

+CGCONTRDP:<cid>,<bearerId>,<apn>[,<ip&subnet>[,<gw_addr>[,<DNS_prim>[,<DNS_sec>[, <P_CSCF_prim>[,<P_CSCF_sec>]]]]]]][<CR><LF>

6 UDP script

An example of UDP communication over NB-IoT is reported below; in this scenario, APN is not required and it set automatically by the network. The module enables NB IoT only. A UDP socket is opened in command mode on xxx.telit.com echo server. "echo_test_UDP" string is sent to the server and echoed back to the module. Incoming data is signalled through SRING unsolicited. AT#SI (Socket Info) command is used to check the data buffered and not yet read. AT#SRECV command is used to read the data. AT#SS command is used to check remote server IP address and socket status.

AT+WS46?

+WS46: 28

OK

AT#WS46?

#WS46: 1

OK

AT+CGDCONT?

+CGDCONT: 1,"IPV4V6","", "0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0",0,0,0,0

+CGDCONT: 2,"IPV4V6","", "0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0",0,0,0,0

...

+CGDCONT: 6,"IPV4V6","", "0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0",0,0,0,0

OK

AT+CEREG?

+CEREG: 0,1

OK

AT+COPS?

+COPS: 0,1,"I TIM",9

OK

AT#MONI

#MONI: I TIM RSRP:-72 RSRQ:-3 TAC:9091 Id:AAFC4A1 EARFCN:6290 PWR:-67dbm

DRX:1024 pci:0 QRxLevMin:0

OK

AT+CGCONTRDP

+CGCONTRDP: 1,5,"nbiot.tids.tim.it", "10.18.13.162", "192.168.200.43", "192.168.200.42"

OK

AT#SGACT?

#SGACT: 1,0

#SGACT: 2,0

...

#SGACT: 6,0

OK

AT#SGACT=1,1
#SGACT: 10.18.13.162,
OK

AT+CGPADDR=1
+CGPADDR: 1,"10.18.13.162"
OK

AT#SGACT?
#SGACT: 1,1
#SGACT: 2,0
...
#SGACT: 6,0
OK

AT#SD=1,1,10510,"xxx.telit.com",0,1234,1
OK

AT#SS
#SS: 1,2,10.18.13.162,1234,185.xxx.xxx.218,10510
#SS: 2,0
#SS: 3,0
...
#SS: 10,0
OK

AT#SEND=1
> echo_test_UDP<CTRL-Z>
OK

SRING: 1

AT#SI
#SI: 1,13,0,13,0
#SI: 2,0,0,0,0
...
#SI: 10,0,0,0,0
OK

AT#SRECV=1,1500
#SRECV: 1,13
echo_test_UDP
OK

AT#SH=1
OK

AT#SS
#SS: 1,0
#SS: 2,0
...
#SS: 10,0
OK

7 TCP script

An example of TCP communication over NB-IoT is reported below; in this scenario, APN is not required and it is set automatically by the network. The module enables NB IoT only. A TCP socket is opened in command mode on xxx.telit.com echo server. "echo_test_TCP" is the data sent to the server and echoed back to the module. Incoming data is signalled through SRING unsolicited. AT#SI (Socket Info) command is used to check the data sent and received. AT#SRECV command is used to read the data. AT#SS command is used to check remote server IP address and socket status. The module starts with radio off, then radio is switched on and attach is performed.

AT+CFUN=4

OK

AT+CFUN=1

OK

AT+CEREG?

+CEREG: 0,2

OK

AT+CEREG?

+CEREG: 0,2

OK

AT+CEREG?

+CEREG: 0,1

OK

AT#RFSTS

#RFSTS: "222 01",6290,-69,-66,-3.0,9091,00,-40,1024,3,1,AAFC4A1,"222013200124051","I
TIM",3,20,720,3240,166

OK

AT+COPS?

+COPS: 0,1,"I TIM",9

OK

AT+CGCONTRDP

+CGCONTRDP: 1,5,"nbiot.tids.tim.it","10.18.15.165",,"192.168.200.43",,"192.168.200.42"

OK

AT#SGACT=1,1

#SGACT: 10.18.15.165,

OK

AT#SD=1,0,10510,"xxx.telit.com",0,0,1

OK

AT#SS

#SS: 1,2,10.18.15.165,36410,185.xxx.xxx.218,10510

#SS: 2,0

...

#SS: 10,0

OK

AT#SEND=1

> echo_test_TCP<CTRL-Z>

OK

SRING: 1**AT#SRECV=1,1500**

#SRECV: 1,13

echo_test_TCP

OK

AT#SI

#SI: 1,13,13,0,0

#SI: 2,0,0,0,0

...

#SI: 10,0,0,0,0


OK

AT#SH=1

OK

8 PSM and eDRX

8.1 PSM/eDRX overview



PSM and eDRX are two different features defined in the latest 3GPP releases. The goal of these features is to reduce the power consumption of IoT devices. To achieve this, PSM and eDRX enable different mechanisms to reduce the signalling between the IoT device and network. The picture above shows the two features combined. However, they can be enabled independently.

The Power Saving Mode (PSM) in 3GPP Rel12 allows the module to skip idle mode tasks for a longer time period while still maintaining the NAS context. This feature permits to reduce the overall power consumption when there is no required data activity with the network for a long time. This saves the power also related to the Paging activity. During the “PSM sleep” period the module is NOT reachable by the network, i.e. it cannot be paged and stops access stratum activities. The module can leave the PSM mode at any point in time when there is MO data or when periodic TAU timer expires.

The extended DRX (eDRX) allows the module to extend the paging period. This feature allows to reduce the overall power consumption increasing radio inactivity time in between paging occasions. The feature is suitable for applications that support high latency communication.

Both features require a negotiation with the network to be enabled. The negotiation happens during the Attach procedure and the Tracking Area Update (TAU).

8.2 PSM script

The module supports 3GPP command AT+CPSMS and custom Telit command AT#CPSMS that simplifies and improve PSM management.

On ME910C1 and ML865C1:

```
AT#CPSMS=[<mode>[,<ReqPeriodicRAU>[,<ReqGPRSreadyTimer>[,<ReqPeriodicTAU>[,<ReqActiveTime>]]]]]
```

The set command controls the setting of the UEs power saving mode (PSM) parameters. The command controls whether the UE wants to apply PSM or not, as well as the requested extended periodic RAU value and the requested GPRS READY timer value in GERAN, the requested extended periodic TAU value in E-UTRAN and the requested Active Time value. Find the relevant parameters below.

<ReqPeriodicTAU> : requested extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN. Parameter expressed in seconds.

<ReqActiveTime> : requested Active Time value (T3324) to be allocated to the UE. Parameter expressed in seconds.

AT#CPSMS?

Read command presents the current CPSMS configuration returned by the network, in the format:

```
#CPSMS: <status>[,<T3324>,<T3412 or T3412EXT>]
```

On ME910G1, ML865G1 and ME310G1:

AT#CPSMS=[<mode>[,<ReqPeriodicRAU>[,<ReqGPRSreadyTimer>[,<ReqPeriodicTAU>[,<ReqActiveTime>[,<psmVersion>[,<psmThreshold>]]]]]]]]

The command has two additional parameters compared to the implementation on ME910C1 and ML865C1: <psmVersion> and <psmThreshold>. The other parameters have the same meaning and functionality as defined for ME910C1 and ML865C1.

<psmVersion>: integer N/A bitmask to indicate PSM modes. Each bit is configured independently.

Default value: <psmValue>=4

Values:

- 0 : PSM without network coordination
- 1 : Rel 12 PSM without context retention
- 2 : Rel 12 PSM with context retention
- 3 : PSM in between eDRX cycles

<psmThreshold>: integer - Minimum duration threshold (in sec) to enter PSM. Default and minimum value is 60 seconds.

Here below a simple script shows the AT#CPSMS functionalities.

AT+COPS?

+COPS: 1,0,"Vodafone@",9 Module is NB-IoT registered
OK

AT#CPSMS?

#CPSMS: 0 PSM feature is OFF
OK

AT#CPSMS=1,0,0,120,20

OK Enable PSM feature: T3412=120s, T3324=20s

A TAU (Tracking Area Update) is triggered, timer negotiation with the network starts; the procedure is fast, unsolicited are disabled we suggest to wait about 2s before proceeding with the next step

AT#CPSMS?

#CPSMS: 1,20,4200 Values that will apply: T3412=4200s, T3324=20s
OK

Timers T3412 and T3324 start when module move from CONNECTED state to IDLE state (RRC Connection Release).

TIMERS START POINT (RRC Connection release)

...

20s

...

Active Time T3324 EXPIRE

The module enters automatically in PSM sleep (module turns off)

E.g. let's assume that at a certain point in time the user wants to use the module to send data; it is possible even if the module is in PSM; the user can wake module up with ON_OFF pin (see turn on procedure defined in HW user guide)

+CEREG: 0

+CEREG: 2

+CEREG: 5,"FFFE","99EE71",9

The module is just turned on and it does not interact with the network, the T3412 timer is still running from TIMERS START POINT

AT#SGACT=1,1

#SGACT: 10.21.115.40
OK

AT#SD=1,0,20510,"2xx.xxx.xxx.xx3" Module now move from IDLE to CONNECTED
CONNECT
echo test message

OK

SRING: 1 Echo is received

AT#SS
#SS: 1,3,10.21.115.40,32468,2xx.xxx.xxx.xx3,20510

...

OK

AT#SH=1 Socket shut down

OK

New TIMERS START POINT: the module was in CONNECTED state, after RRC Connection Release from the network it moves to IDLE state, this reset the two timers

TIMERS START POINT (RRC Connection release)

...

20s

...

Active Time T3324 EXPIRE

The module enters automatically in PSM sleep (module turns off)

...

4180s (T3412-T3324)

...

Tracking Area Update period T3412 EXPIRE

The module exits automatically from PSM sleep (module turns on); Tracking Area Update is triggered

+CEREG: 0

+CEREG: 2

+CEREG: 5,"FFFE","99EE71",9

8.3 eDRX script

The modules support 3GPP commands AT+CEDRXS, AT+CEDRXRDP and custom Telit command AT#CEDRXS that simplifies and improve eDRX management.

AT#CEDRXS=[<mode>[,<AcTtype>[,<Req_eDRX>[,<ReqPagTimeWindow>]]]]

Set command controls the setting of the UEs eDRX parameters. The command controls whether the UE wants to apply eDRX or not, as well as the requested eDRX value for each specified type of access technology. Find the relevant parameters below.

<AcTtype> : integer N/A type of access technology.

Values:

0 : Access technology is not using eDRX

2 : GSM (A/Gb mode)

4 : E-UTRAN (CAT M1 mode)

5 : E-UTRAN (NB1 mode)

<Req_eDRX> : half a byte in a 4 bit format. The eDRX value refers to bit-4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008). For the coding and the value range, see Extended DRX parameters information element in 3GPP TS 24.008, Table 10.5.5.32/3GPP TS 24.008. Default value is "0000".

AT#CEDRXS?

Read command returns the current settings for each defined value of <AcTtype> in the format:

**#CEDRXS:<AcTtype>,<eDRX_act_state>,<Req_eDRX>,<ReqPagTimeWindow>
[,<NW_prov_eDRX>[,<NW_prov_PagTimeWindow>]]**

Here below a simple script shows the AT#CEDRXS functionalities. The test is performed using a network simulator but the same can be applied on live network.

AT+CEREG?

+CEREG: 0,1
OK

AT+COPS?

+COPS: 0,0,"Test 001 01",8
OK

The module is registered to CAT M test network

AT#RFSTS

#RFSTS: "001 01",1575,-85,-65,-3.0,0001,00,,256,3,0,0000100,"001012345678901","Test 001 01",3,3,720,3240,249
OK

AT#CEDRXS?

#CEDRXS: 2,0,"0000","0000"
#CEDRXS: 4,0,"0000","0000"
#CEDRXS: 5,0,"0000","0000"
OK

eDRX is disabled on all access technologies

AT#CEDRXS=1,4

OK

eDRX enabled without specifying timings

A TAU (Tracking Area Update) is triggered, values negotiation with the network starts; the procedure is fast but we suggest to wait about 2s before proceed with next step

AT#CEDRXS?

#CEDRXS: 2,0,"0000","0000"
#CEDRXS: 4,1,"0000","0000",1,"0010","0000"
#CEDRXS: 5,0,"0000","0000"
OK

The network returns the following eDRX timings for the CAT M connection:

<NW_prov_eDRX> : 0010=20,48s
<NW_prov_PagTimeWindow> : 0000=1,28s

AT#CEDRXS=0,4

OK

eDRX disabled, TAU is triggered

AT#CEDRXS?

#CEDRXS: 2,0,"0000","0000"
#CEDRXS: 4,0,"0000","0000"
#CEDRXS: 5,0,"0000","0000"
OK

AT#CEDRXS=1,4,"0001","0001"

OK

eDRX enabled with some specific values, but test network is setup to support only:

eDRX 20,48s

Paging Time Window 1,28s

TAU is triggered and values are exchanged with the network

AT#CEDRXS?

#CEDRXS: 2,0,"0000","0000"

#CEDRXS: 4,1,"0001","0001",1,"0010","0000"

#CEDRXS: 5,0,"0000","0000"

OK

The network applies the supported values

<NW_prov_eDRX> : 0010=20,48s

<NW_prov_PagTimeWindow> : 0000=1,28s

AT+CFUN=4

Module detach

OK

If we change the eDRX supported parameters on test network, e.g.:

eDRX 40,96s

Paging Time Window 2,56s

AT+CFUN=1

OK

During the attach procedure module asks the network to enable eDRX using the previous settings

AT#CEDRXS?

#CEDRXS: 2,0,"0000","0000"

#CEDRXS: 4,1,"0001","0001",1,"0011","0001"

#CEDRXS: 5,0,"0000","0000"

OK

The network applies the new supported values

<NW_prov_eDRX> : 0011=40,96s

<NW_prov_PagTimeWindow> : 0001=2,56s

8.4 PSM in between eDRX script

Within the eDRX modality the modules can activate a proprietary powersave management to fully enhance eDRX power consumptions when eDRX cycle is greater than a specific value (typically above 2-3 minutes).

The solution is using “PSM power state” in between eDRX PTWs in order to lower the current consumption to 3uA.

Since the module is practically OFF a tiny boot process is needed before being ready for the Paging Time Window, this is accomplished with an anticipated wakeup.

To be noted that this modality doesn't actually activate standard 3GPP PSM, this solution just take advantage of the PSM power state of 3uA in between eDRX, i.e. when module is not in the active paging task window.

When PSM in between eDRX is activated the AT modem interface is not available. The module can be awakened at every time by using ON_OFF line.

Differently from standard eDRX this proprietary modality cannot be combined with PSM (as shown in figure 8.1) and needs a specific command plus a reboot to take effect.

The feature is available on ME910G1, ML865G1 and ME310G1.

Here below a simple script to perform PSM inbetween eDRX. The test is performed using a network simulator but the same can be applied on live network.

AT+CEREG?

```
+CEREG: 0,1
OK
```

AT+COPS?

```
+COPS: 0,0,"Test 001 01",8
OK
```

The module is registered to CAT M test network

AT#RFSTS

```
#RFSTS: "001 01",1575,-85,-65,-3.0,0001,00,,256,3,0,0000100,"001012345678901","Test
001 01",3,3,720,3240,249
OK
```

AT#CPSMS=1,,,90,20,8,60

PSM in between eDRX mode is activated with a PSM threshold of 60 sec

Before giving this command be sure PSM is disabled (#CPSMS: 0).

When using PSM in between eDRX, <psmThreshold> has the following meaning: PSM in between eDRX will be activated if assigned (eDRX cycle – PTW) > psmThreshold. Otherwise standard eDRX is activated.

AT#REBOOT

AT#CEDRXS?

eDRX is disabled on all access technologies

#CEDRXS: 2,0,"0000","0000"

#CEDRXS: 4,0,"0000","0000"

#CEDRXS: 5,0,"0000","0000"

OK

AT#CEDRXS=1,4

eDRX enabled without specifying timings that will be assigned by the network (Network Simulator)

OK

A TAU (Tracking Area Update) is triggered, values negotiation with the network starts; the procedure is fast but we suggest to wait about 2s before proceed with next step

AT+CEDRXRDP

+CEDRXRDP: 4,"0101","0101","1111"

The network returns the following eDRX timings for the CAT M connection:

<NW_prov_eDRX> : 0101= 81,92 s

<NW_prov_PagTimeWindow> : 1111=20,48 s

AT#CEDRXS=0,4

eDRX disabled, TAU is triggered

OK

AT#CEDRXS?

#CEDRXS: 2,0,"0000","0000"

#CEDRXS: 4,0,"0000","0000"

#CEDRXS: 5,0,"0000","0000"

OK

8 Document History

Revision	Date	Changes
0	2018-02-14	First registered issue
1	2018-03-01	Updated Applicability Table Document restyling Updated PSM and added new eDRX script
2	2019-12-06	Document restyling Added section 2.3 – Warning on Windows Cellular connection Modified and updated chapter 4 – Network registration Updated chapter 5 – Check/Set data service Modified and updated chapter 6 – UDP script Modified and updated chapter 7 – TCP script Modified and updated chapter 8 – PSM and eDRX
3	2020-07-22	Updated document tile Updated Applicability Table Updated section 1.4 – Related Documents Added new section 2.2 – ME910G1, ML865G1, ME310G1 Main Features Updated graph in section 8.1 – PSM/eDRX Overview Updated section 8.2 – PSM Script Added new section 8.4 – PSM in between eDRX script



SUPPORT INQUIRIES

Link to www.telit.com and contact our technical support team for any questions related to technical issues.

www.telit.com



Telit Communications S.p.A.
Via Stazione di Prosecco, 5/B
I-34010 Sgonico (Trieste), Italy

Telit Wireless Solutions Inc.
3131 RDU Center Drive, Suite 135
Morrisville, NC 27560, USA

Telit Wireless Solutions Ltd.
10 Habarzel St.
Tel Aviv 69710, Israel

Telit IoT Platforms LLC
5300 Broken Sound Blvd, Suite 150
Boca Raton, FL 33487, USA

Telit Wireless Solutions Co., Ltd.
8th Fl., Shinyoung Securities Bld.
6, Gukjegeumyung-ro8-gil, Yeongdeungpo-gu
Seoul, 150-884, Korea

Telit Wireless Solutions
Tecnologia e Servicos Ltda
Avenida Paulista, 1776, Room 10.C
01310-921 São Paulo, Brazil

Telit reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. The information contained herein is provided "as is". No warranty of any kind, either express or implied, is made in relation to the accuracy, reliability, fitness for a particular purpose or content of this document. This document may be revised by Telit at any time. For most recent documents, please visit www.telit.com

Copyright © 2016, Telit

Mod. XXXX